








How to read the table: Find your desired sample storage tube or sample storage rack and see which rack/tube, rack cover and cap is compatible.

Rack type →	Micronic 48-1	Micronic 48-2	Micronic 48-3	Micronic 48-4	Micronic 24-1	Micronic 24-2	Micronic 24-4
Tube size ↓							
Cover	Low	High	High	High	High	Low	High
1.00ml external thread	Screw Cap						
1.50ml external thread hybrid						Screw Cap	
2.00ml external thread hybrid		Screw Cap					
3.00ml external thread hybrid 48-well			Screw Cap				
3.00ml external thread hybrid 24-well					Screw Cap		
3.50ml external thread						Screw Cap	
4.00ml internal thread				Screw Cap			
4.00ml external thread				Screw Cap			
6.00ml internal thread							Screw Cap
6.00ml external thread hybrid							Screw Cap

Micronic Europe

(Asia, Africa, Europe, Oceania)

Tel: +31 (0)320 277070

Micronic America

(North, Central and South America)

Tel: +1 484 480 3372

E-mail: sales@micronic.com

www.micronic.com